


Quick Reference Guide





Connecting a **RCKT** to
your **iPhone**


1. Power on your **RCKT**. It will then display a **Device Name**.




2. Download the **ValorPay App** from your **iPhone's App Store**. Allow **Notifications** for the Application.




3. Login to the **ValorPay App** with your **Username**. A **One-Time Password** will be sent to your mobile device on file for logging in.







4. After entering the OTP, the user must create a **6-digit Passcode** for secure and easy access to the ValorPay app.



5. Select the **switch icon** on the top right corner of the mobile application to change the **Stores** and **Devices**.




6. Select your **Store** and your **device EPI** from the list of available stores and devices.




7. Upon selecting the **EPI**, a new screen appears that scans for all nearby RCKT devices. Select the right device name to pair with.

Note: Ensure that **Bluetooth** and **Location** permissions are enabled.



8. Your **RCKT** is now **paired**, the RCKT screen appears as the screen below.




Download our app **now!** Scan the QR code below.



Available on the iPhone

App Store



Visit Our Knowledge Base

Scan the QR Code with your mobile device to search for troubleshooting articles.



VALOR
PAYTECH

© 2025 Valor PayTech

M: sales@valorpaytech.com

P: 1.800.615.8755

[in](#) [@](#) [v](#) [f](#) [X](#)

THE FUTURE OF PAYMENT TECHNOLOGY