

# Quick Reference Guide





# RCKT


Dual Pricing

# Performing a Sale


1. To switch to **Sale** from the Payment type, select the dropdown on the left to **Quick Sale**.




2. In the display, there's a clear distinction of **card**, **EBT** and **cash** sale. Enter the transaction amount and select **Process Payment**.




3. Select a **Payment Method** by which you want to execute the transaction.





4. Select **Continue** after entering the customer mobile number and Email address.




5. The application prompts the user to **initiate payment** using the **RCKT** device by **Tap, Swipe, or Insert** provision available.




6. **ValorPay** and the **RCKT** device will display a screen to **enter** the **PIN** to authenticate the transaction.



7. On completion of the transaction, the mobile application prompts a confirmation screen showing the **transaction** execution **status**.



# Terminal Guide



1. Power

2. Delete

3. Cancel

4. OK

5. Down

6. Up

7. Tap

8. Swipe

9. Charging port

10. Insert

## Visit Our Knowledge Base

Scan the QR Code with your mobile device to search for troubleshooting articles.



© 2025 Valor PayTech

M: [sales@valorpaytech.com](mailto:sales@valorpaytech.com)

P: 1.800.615.8755

[in](#) [@](#) [v](#) [f](#) [X](#)