


Quick Reference Guide



VP550E

Android POS



Transactions

CREDIT SALE

1. Enter **Transaction Amount** and tap **Enter**.
2. **Swipe/Insert/Tap** card on **Present Card** screen.
For **Manual Key Entry**, select the **Enter Manually** option.
3. **Sign** and **Tip** if prompted.
4. Select receipt delivery method.

DEBIT SALE

1. Tap **Credit** until **Debit** is displayed.
2. Enter **Transaction Amount** and tap **Enter**.
3. **Swipe/Insert/Tap** card on **Present Card** screen.
For **Manual Key Entry**, select the **Enter Manually** option.
4. Enter **PIN** and **Tip** if prompted.
5. Follow prompts until receipt prompt-select receipt delivery method.

CREDIT VOID

1. Tap **Sale** until **Void** is displayed.
2. Enter the **Transaction Number** from the receipt or the **last 4 of the card number** and tap **Enter**.
3. When prompted enter **Password**.
4. Tap to confirm the transaction that needs to be voided.
5. Select receipt delivery method.

CREDIT REFUND

1. Tap **Sale** until **Refund** is displayed.
2. Enter **Transaction Amount** and tap **Enter**.
3. **Swipe/Insert/Tap** card on **Present Card** screen.
For **Manual Key Entry**, select the **Enter Manually** option.
4. Select receipt delivery method.

CREDIT PREAUTH

1. Tap **Sale** until **Preauth** is displayed.
2. Enter **Transaction Amount** and tap **Enter**.
3. **Swipe/Insert/Tap** card on **Present Card** screen.
For **Manual Key Entry**, select the **Enter Manually** option.
4. Select receipt delivery method.

CAPTURE PREAUTH

1. Tap **Sale** until **Ticket** is displayed.
2. Enter **Transaction Amount**, tap **Enter** and enter **Password**.
3. Enter the **Transaction Number** from the receipt or the **last 4 of the card number** and tap **Enter**.
4. **Sign** and **Tip** if prompted.
5. Select receipt delivery method.



Main Menu Options

REPORTS

See summary reports for current open batch, the last settled batch, and the detailed reports of the last 5 batches settled.

SETTLEMENT

Option to settle the current batch.

TIP ADJUST

Adjust the tip amount on transactions performed within current batch.

PRE SALE

Generates a Pre-Sale ticket.

UPDATES

Used to apply parameter changes or update the version on the device.

SETTINGS


Configure settings on the device such as Server/Clerk, Change Password, Wifi Config, SIM Config, and Utilities.



Connect to WiFi

1. From the **Home Screen**, tap the **Main Menu icon**.
2. Tap **Settings**, then **WiFi Config**
3. Tap **SSID**
4. Enter **WiFi Password** (Password is case sensitive)
5. Tap **Connect**

Terminal Guide



1. Camera

2. Connection Icon

3. Battery Level

4. Home

5. Main Menu

6. Back

Visit Our Knowledge Base

Scan the QR Code with your mobile device to search for troubleshooting articles.



© 2024 Valor PayTech

M: sales@valorpaytech.com

P: 1.800.615.8755

[f](#) [X](#) [i](#) [v](#) [in](#)